



ER COILFORMERS



COILFORMER DIMENSIONS (mm)													
TYPE	A	B	C	D	E	F	G	H	I	J	K	L	M
E9.5	7.3	4.45	3.6	0.70	2	6	8.6	0.25	4.4	8.1	11.7	2.05	2.95
E11	8.5	5.3	4.5	0.70	4	8	10.6	0.25	4.4	9.2	12.35	1.85	2.8
E14.5	11.4	5.9	5	0.70	5	10	14	0.25	5.2	-	16.25	1.9	3

ER CORES

CORE DIMENSIONS (mm)							
TYPE	A	B	C	D	E	F	G
ER9.5	1.6	2.45	7.5	7.1	3.5	9.5	5
ER11	1.5	2.45	8.7	8	4.25	11	6
EP14.5	1.55	2.95	-	11.8	4.8	14.5	6.8



EP COILFORMER FOOTPRINTS

Hole arrangement view in mounting direction. All dimensions in mm.

ER9.5	ER11	EP14.5